


Steri-Quartz T

SYSTEM INFORMATION SHEET



1/8 to 1/4-inch (3 to 6 mm)

SYSTEM STEPS

- ① Concrete Substrate
- ② Steri-Prime
- ③ Steri-Flor UV clear w/ Quartz
- ④ Steri-Flor UV clear
- ⑤ Sealer 35 clear



DECORATIVE

The Steri-Quartz T system can be customized to meet any number of color schemes.



ABRASION RESISTANT

The filler used in this system protects against abrasion and breakdown of the epoxy resin, allowing for asset longevity.



HIGH COMPRESSIVE STRENGTH

Steri-Quartz T is an epoxy mortar that utilizes high strength filler throughout the entire thickness of the system.

Steri-Quartz T

SYSTEM INFORMATION SHEET



PERFORMANCE DATA	TEST METHOD	RESULTS
	Compressive Strength (ASTM C579)	7,000-9,000 PSI (48-62 MPa)
	Tensile Strength (ASTM C307)	1,800-2,000 PSI (12-14 MPa)
	Flexural Strength (ASTM C580)	2,500-2,700 PSI (17-19 MPa)
	Flame Spread (ASTM D635)	<5mm / self extinguishing
	Tensile Bond Strength (ASTM D7234)	Cohesive failure of concrete

SYSTEM STEPS	PRODUCT	THICKNESS	THEORETICAL COVERAGE RATE	PACKAGING	APPLICATION EQUIPMENT	RECOAT / DRY TIME*
Primer	Steri-Prime	3-4 mils (75-100 microns)	340-450 ft ² /gal (8.3-11 m ² /liter)	Part A Part B	Flat Squeegee / Short Nap Roller	6 hours (min) 5 days (max)
Use a short-nap roller cover with solvent resistant core. For best results, condition roller before application to minimize lint or loose fibers. A high quality solvent resistant brush may be used for hard to reach areas. Prime all surfaces to be coated at 3-4 mils (75-100 microns). Do not allow primer to puddle.						
Bodycoat	Steri-Flor UV with Quartz (25-A)	3/16" (5 mm)	142 ft ² @ 3/16" per 6 bag kit (13.2 m ² @ 5 mm per 6 bag kit)	Part A Part B Quartz Filler 25-A (x 6)	Screed Box / Trowel / Power Trowel	8 hours (min) 24 hours (max)
For optimum results, finish the topping with a 48 - 52 inch power trowel within 10-20 minutes of placement. Over-trowelling can lead to blistering and excessive burnishing. Final finishing using a hover trowel (if available) can achieve an extremely smooth and tightly closed surface. Applicators must wear spiked shoes to avoid depressions while power-trowelling.						
Groutcoat	Steri-Flor UV	10-20 mils (250-500 microns)	80-160 ft ² /gal (2-4 m ² /liter)	Part A Part B	Squeegee / Short Nap Roller	8 hours (min) 24 hours (max)
The mixed product should be immediately poured directly onto the floor in ribbons and spread to desired thickness with a flat squeegee. After spreading the material to the proper thickness, roll with a short nap roller to level.						
Sealer	Sealer 35	3-4 mils (75-100 microns)	360-480 ft ² /gal (9-12 m ² /l)	Part A Part B	Short Nap Roller	8 hours (min)
The mixed product should be dipped and rolled. Rolling with a short-nap, shed-resistant roller is recommended. Brush application should only be employed for cut in, small areas, touch ups, and repairs. When using High Wear Filler stir frequently to keep it in suspension. The surface must be abraded before recoating with itself or any other product.						

*Recoat time at 75°F (24°C).

Steri-Quartz T

SYSTEM INFORMATION SHEET



COVING					
PRODUCT	GENERIC TYPE	THICKNESS	THEORETICAL COVERAGE RATE	PACKAGING	APPLICATION EQUIPMENT
Steri-Cove Gel	Thixotropic Epoxy	1/8" thickness (1" radius) at 4" height = 47 lineal ft (3 mm at 102 mm height = 14.3 m) 1/8" thickness (1" radius) at 6" height = 33 lineal ft (3 mm at 152 mm height = 10 m) 3/16" thickness (1" radius) at 4" height = 40 lineal ft (5 mm at 102 mm height = 12 m) 3/16" thickness (1" radius) at 6" height = 30 lineal ft (5 mm at 152 mm height = 9 m)		Part A Part B	Coving Trowel
Apply a tack coat of neat Steri-Cove Gel, then place mixed Steri-Cov Gel mortar at the floor to wall transition and smooth with a 1" radius coving trowel. Note: If the tack coat cures before the mortar is applied – re-apply tack coat. Use of plastic or metal termination strip at the top of the cove is recommended.					

INSTALL

This document is meant as a guideline for the installation of the system. Contact Dudick for further assistance prior to the installation of the system.

SURFACE PREPARATION

Concrete must be prepared mechanically to remove surface laitance. Oils, grease or other contaminant must be removed prior to surface preparation. Concrete must be free of curing compounds and form release agents. Surface texture should be similar to 30-40 grit sandpaper or the visual standard, CSP-5 from the International Concrete Repair Institute. The prepared surface should have a minimum tensile strength of 250 psi per ASTM D7234.

Concrete substrates must be checked for moisture prior to product application using the Plastic Sheet Test, ASTM D4263. If moisture is found to be present, contact Dudick for further recommendations.

MIXING

All mixing should follow the mixing instructions on the specific Product Data pages.



Dudick is part of Carboline
 1818 Miller Parkway
 Streetsboro, Ohio 44241
 1-800-322-1970

NOTE: The technical data presented in this document is accurate to the best of Dudick and Carboline's knowledge based on laboratory testing of the product(s) or system(s) described. Actual results in the field may vary depending on field conditions and application methods. The performance characteristics stated do not constitute a guarantee or warranty that the products will meet the stated results under all circumstances. Contact Dudick or Carboline technical staff with questions.

00-46-0724-D116